

FURUKAWA HD609-I Drifter Parts for HCR9 Crawler Drill

FURUKAWA HD609-I

No	Crawler Drill	Drifter	Part Number	Part Name	Q'ty	Unit Price	Remarks
	HCR 9	HD609-I	HD609-01010	Cylinder(B)			
1	HCR 9	HD609-I	008110-10005	Plug			
2	HCR 9	HD609-I	160011-00011	O-Ring			
3	HCR 9	HD609-I	007520-10004	3/4 Plug			
4	HCR 9	HD609-I	008210-10016	1/8 Plug			
5	HCR 9	HD609-I	Hd609-01005	Stroke Adjuster			
6	HCR 9	HD609-I	050300-02034	Seal Washer(A)			
7	HCR 9	HD609-I	008110-10004	Nut			
8	HCR 9	HD609-I	HD609-01011	Bush (F)			
9	HCR 9	HD609-I	HD609-01002	Seal Retainer (F)			
10	HCR 9	HD609-I	HB20G-10121	Bush			0.02
11	HCR 9	HD609-I	HB10G-10121	Bush			0.02
12	HCR 9	HD609-I	HD609-01102	Piston(B)			
13	HCR 9	HD609-I	HD609-01308	Valve(B)			
14	HCR 9	HD609-I	HD609-01309	Valve Plug (B)			
15	HCR 9	HD609-I	HD609-01303	Bush (R)			
16	HCR 9	HD609-I	HD609-01304	Seal Retainer (R)			
17	HCR 9	HD609-I	HD609-02001	Front Head			
18	HCR 9	HD609-I	HD609-02002	Thrust Bush			1.2kg
19	HCR 9	HD609-I	HD609-02003	Plain Bearing (B)			1.2kg
20	HCR 9	HD609-I	HD609-02004	Thrust Washer (B)			
21	HCR 9	HD609-I	HD609-02005	Chuck Driver			9kg
22	HCR 9	HD609-I	HD609-02006	Chuck Driver Bush			1.2kg
23	HCR 9	HD609-I	HD609-02012	Chuck (E)			3.5kg
24	HCR 9	HD609-I	HD609-02008	Drive Gear			
25	HCR 9	HD609-I	280100-06209	Ball Bearing			
26	HCR 9	HD609-I	HD609-02101	Front Cover			
27	HCR 9	HD609-I	HD609-02102	Plain Bearing (A)			1.1kg
28	HCR 9	HD609-I	HD170-02015	3/4 Elbow Connector			
29	HCR 9	HD609-I	HD612-02105	1/2-3/8 Elbow Connector			
30	HCR 9	HD609-I	HD609-02103	Thrust Washer (A)			1kg
31	HCR 9	HD609-I	HD609-02111	Thrust Washer (C)			
32	HCR 9	HD609-I	HD609-02201	Front Cap			
33	HCR 9	HD609-I	HD609-02202	Front Bush			0.7
34	HCR 9	HD609-I	007620-40005	U-Packing			0.02
35	HCR 9	HD609-I	HD609-02203	Swivel Body			
36	HCR 9	HD609-I	007620-40003	U-Packing			0.02
37	HCR 9	HD609-I	HD609-03001	Back Head			
38	HCR 9	HD609-I	007520-10004	3/4 Plug			
39	HCR 9	HD609-I	HD609-03006	Reducing Check Elbow			
40	HCR 9	HD609-I	007520-10007	3/4 Street Union Adapter			
41	HCR 9	HD609-I	HD170-02015	3/4 Elbow Connector			
42	HCR 9	HD609-I	HD612-03002	3/4-1/2 Elbow Connector			
43	HCR 9	HD609-I	007210-30002	Knock Pin			
44	HCR 9	HD609-I	HD609-03602	Through Bolt (M1)			

No	Crawler Drill	Drifter	Part Number	Part Name	Q'ty	Unit Price	Remarks
45	HCR 9	HD609-I	HD609-03603	Through Bolt (M2)			
46	HCR 9	HD609-I	001700-36102	20 Nut			
47	HCR 9	HD609-I	HD609-03604	Through Bolt (R)			
48	HCR 9	HD609-I	HD609-03601	Through Bolt (F)			
49	HCR 9	HD609-I	HD609-03611	Set Bolt			
50	HCR 9	HD609-I	001200-36012	27 Nut			
51	HCR 9	HD609-I	HD280-60001	Orbit Motor			
52	HCR 9	HD609-I	001602-10008	Hose Adapter			
53	HCR 9	HD609-I	007120-60010	Socket Bolt			
54	HCR 9	HD609-I	007320-60003	Washer			
55	HCR 9	HD609-I	007010-60012	Nut			
56	HCR 9	HD609-I	HD606-97002	Accumulator Assembly			
57	HCR 9	HD609-I	102032-20085	20 Socket Bolt			
58	HCR 9	HD609-I	HD609-92301	Extraction Assembly			
59	HCR 9	HD609-I	HD609-92302	Extraction Assembly			
60	HCR 9	HD609-I	040001-01014	Track Bearing			
61	HCR 9	HD609-I	915001-01023	Floating Seal Set			
62	HCR 9	HD609-I	922001-04004	Front Idler			
63	HCR 9	HD609-I	02001-04005	Bush			
64	HCR 9	HD609-I	02001-04006	Idler Shaft			
65	HCR 9	HD609-I	922001-05032	Track Roller			
66	HCR 9	HD609-I	923001-07001	Carrier Roller			
67	HCR 9	HD609-I	923001-02002	Drive Motor			
68	HCR 9	HD609-I	023001-02006	Drive Sprocket			
69	HCR 9	HD609-I	940001-07001	Track Link Shoe			
70	HCR 9	HD609-I	022001-06010	Track Pin			
71	HCR 9	HD609-I	022001-06011	Master Pin			
72	HCR 9	HD609-I	022001-06017	Shoe Plate			
73	HCR 9	HD609-I	940202-00001	Compressor			
74	HCR 9	HD609-I	023203-08004	Upper Hose			
75	HCR 9	HD609-I	023203-08005	Lower Hose			
76	HCR 9	HD609-I	940102-02044	Gear Box			
77	HCR 9	HD609-I	040102-04005	Coupling			
78	HCR 9	HD609-I	040102-04010	Flange			
79	HCR 9	HD609-I	040102-04011	Rubber Box			
80	HCR 9	HD609-I	940102-05001	Plunger Pump (A51)			
81	HCR 9	HD609-I	940102-06001	Plunger Pump (B10)			
82	HCR 9	HD609-I	940102-06002	Gear Pump			
83	HCR 9	HD609-I	040203-02002	Oil Separator			
84	HCR 9	HD609-I	023104-01006	Suction Hose			
85	HCR 9	HD609-I	088110-01002	Oil Motor			
86	HCR 9	HD609-I	023103-09008	Fan			
87	HCR 9	HD609-I	023103-09010	Radiator			
88	HCR 9	HD609-I	981900-00023	Guide Shell			
89	HCR 9	HD609-I	081900-01008	Front Sprocket			
90	HCR 9	HD609-I	083002-01014	Sprocket			
91	HCR 9	HD609-I	081300-05032	Half Bushing T38			
92	HCR 9	HD609-I		Half Bushing T45			
93	HCR 9	HD609-I	981900-03034	Carriage			

No	Crawler Drill	Drifter	Part Number	Part Name	Q'ty	Unit Price	Remarks
94	HCR 9	HD609-I	081900-03035	Carriage			
95	HCR 9	HD609-I	030800-03039	Guide Plate			
96	HCR 9	HD609-I	030800-03049	Wear Plate			
97	HCR 9	HD609-I	083002-02012	Sprocket (100)			
98	HCR 9	HD609-I	082200-02009	Roller			
99	HCR 9	HD609-I	088110-04006	Hood			
100	HCR 9	HD609-I	988110-04066	Seal Rubber			
101	HCR 9	HD609-I	970402-00001	Feed Motor			
102	HCR 9	HD609-I	970402-00002	Seal Kit			
103	HCR 9	HD609-I	970402-00003	Seal Kit			
104	HCR 9	HD609-I	970402-00004	Seal Kit			
105	HCR 9	HD609-I	088402-010200	Element			
106	HCR 9	HD609-I	082005-03002	Roller			
107	HCR 9	HD609-I	982005-04002	Orbit Motor			
108	HCR 9	HD609-I		Drifter Seal kit HCR 9 Mark I			
109	HCR 9	HD609-I	NOK AP0817H	HCR 9 (NOK AP0817H)			
110	HCR 9	HD609-I	HD609-99103	Hydraulic Drifter Seal Kit 1 SET			



e-trade
ENGINEERING