

## FURUKAWA HD75 Drifter Parts

### FURUKAWA HD75

No	Crawler Drill	Drifter	Part Number	Part Name	Q'ty	Unit Price	Remarks
		HD75	908110-00004	HYDRAULIC DRIFTER			
1		HD75	008110-10001	CYLINDER			
2		HD75	008110-10002	SEAL RETAINER (F)			
3		HD75	008110-10003	STROKE ADJUSTER			
4		HD75	008110-10004	NUT			
5		HD75	008110-10005	1/4 PLUG			
6		HD75	008110-10006	U-PACKING			
7		HD75	008110-10007	SEAL WASHER			
8		HD75	007410-13005	DUST SEAL			
9		HD75	008110-11002	PISTON	1		2.80 KG
10		HD75	008110-13001	VALVE	1		1.5 KG
11		HD75	008110-13002	VALVE PLUG	1		0.6 KG
12		HD75	008110-13003	BUSHING			0.5 KG
13		HD75	008110-13004	U-PACKING			
14		HD75	008110-13005	DUST SEAL			
15		HD75	008110-13006	SEAL RETAINER (R )			
16		HD75	160011-00011	O-RING			
17		HD75	160021-00045	O-RING			
18		HD75	262022-00045	BACK UP RING			
19		HD75	160021-00065	O-RING			
21		HD75	160021-00060	O-RING			
22		HD75	262022-00060	BACK UP RING			
23		HD75	160011-00018	O-RING			
24		HD75	160011-00024	O-RING			
25		HD75	007520-10004	3/4 PLUG			
26		HD75	023004-04021	PF 1/2-PF1/2 ADAPTER			
27		HD75	007620-10002	BUSHING			
28		HD75	007120-10039	O-RING			
29		HD75	007120-30002	KNOCK PIN			
30		HD75	008110-20032	FRONT HEAD			
31		HD75	008110-20005	FRONT COVER			
32		HD75	008110-20004	FRONT CAP			
33		HD75	008110-20011	PLAIN BEARING (A)			
34		HD75	008110-20012	PLAIN BEARING (B)			
35		HD75	008110-20031	THRUST BUSHING			
36		HD75	008110-20027	CHUCK			1.5kg
37		HD75	008110-20015	CHUCK DRIVER			6.2kg
38		HD75	008110-20016	DRIVE GEAR			
39		HD75	008110-20017	THRUST BUSHING			
40		HD75	008110-20018	1/2 PLUG			
41		HD75	280080-06208	BALL BEARING			0.4kg
42		HD75	008110-20007	SWIVEL DRIVER			
43		HD75	008110-20008	FRONT BUSHING			0.54kg
44		HD75	008110-20006	THRUST BUSHING			
45		HD75	008110-20009	PLAIN BEARING			

No	Crawler Drill	Drifter	Part Number	Part Name	Q'ty	Unit Price	Remarks
46		HD75	008110-20010	PLAIN BEARING			
47		HD75	024104-27008	PF 3/4-PF 1/2 ADAPTER			
48		HD75	160021-00070	O-RING			
49		HD75	260022-00070	BACK UP RING			
50		HD75	008110-20024	O-RING			
51		HD75	008110-20030	CHUCK DRIVER BUSHING			1.0kg
52		HD75	160011-00016	O-RING			
53		HD75	161011-00012	O-RING			
54		HD75	008110-25004	SHANK ROD R38			
55		HD75	008110-02503	SHANK T38*L425			3.44kg
		HD75		SHANK T38*L425			
		HD75	008110-30001	BACK HEAD			
56		HD75	008110-36001	THROUGH BOLT (A)			
57		HD75	008110-36002	THROUGH BOLT (B)			
58		HD75	D95-352	NUT			
59		HD75	008110-40001	SWIVEL BODY			
60		HD75	008110-40002	QUAD RING			
61		HD75	008110-40003	BACK UP RING			
62		HD75	085610-40559	U-PACKING			
63		HD75	007520-60001	ORBIT MOTOR			
64		HD75	008110-60004	FLANGE ADAPTER			
65		HD75	008110-60003	BOLT			
66		HD75	007010-60004	1/2 BONDED SEAL			
67		HD75	084801-04000	12 MALE ADAPTER			
68		HD75	007010-30004	JOINT SLEEVE			
69		HD75	007210-60002	SOCKET BOLT			
70		HD75	007210-60003	NUT			
71		HD75	908110-70002	ACCUMULATOR ASSEMBLY			
72		HD75	008110-70001	ACCUMULATOR BODY			
73		HD75	008110-70005	ACCUMULATOR COVER			
74		HD75	007210-70013	DIAPHRAGM			0.03kg
75		HD75	007120-70134	VALVE			0.04kg
76		HD75	007010-70029	CAP			
77		HD75	007010-70030	PLUG			
78		HD75	160011-00005	O-RING			
79		HD75	160011-00014	O-RING			
80		HD75	161021-00055	O-RING			
81		HD75	007010-10019	18 WASHER			
82		HD75	007010-10018	SOCKET BOLT			
83		HD75	160021-00025	O-RING			
		HD75		SEAL KIT			Incl. 2 diaphragms

ENGINEERING